





PARTI DI RICAMBIO - SPARE PARTS LIST

2HMS Serie - Series

ITEM N.	DESCRIZIONE	DESCRIPTION	Q.TA' Q.TY	CODICE - CODE							
				2HMS3/A	2HMS3T/A	2HMS4R/A	2HMS4RT/A	2HMS4/A	2HMS4T/A	2HMS7/A	2HMS7T/D
				107310000	107310050	107310010	107310060	107310020	107310070	107310030	104460190
				0,3 kW	0,3 kW	0,45 kW	0,45 kW	0,45 kW	0,45 kW	0,75 kW	0,75 kW
1	Corpo pompa	Pump body	1	151301640		151301650		151301720		151301730	
*	2 Girante	Impeller	N	150702160							
3	Scatola stadio iniziale	Initial stage box	1	152801060							
4	Diffusore	Diffuser	N-2	-				152800900			
5	Diffusore finale	Final diffuser	1	152801300							
6	Disco portatenuta	Seal holding disc	1	160102430							
7	Supporto motore/pompa	Motor/pump support	1	161430650						161430660	161430800
8	Albero-rotore-cuscinetti-sporg.	Shaft-rotor-bearings-extension	1	155108080		155108090		155108100		155108111	155108400
9	Cassa motore c/statore	Motor case w/stator	1	KR0100000	KR0100100	KR0100200	KR0100300	KR0100200	KR0100300	KR0100800	KL25ADE
10	Coperchio motore	Motor cover	1								
11	Ventola	Fan	1	140760150						140760160	
12	Copriventola	Fan cover	1	KL29AAC						KL29AAD	KL29AAE
*	13 Tenuta meccanica + OR	Mechanical seal + OR	1	148992571							
*	14 Cuscinetto ant.+ post.	Front + rear bearing	1	KL11AAC						KL11AAB	KL11AAU
15	Anelli tenuta	Seal rings	1	KL03ABP							
16	Connettore Plug-in	Plug-in element	1	158160600	158160280	158160620	158160280	158160620	158160280	158160680	158160280
17	Condensatore	Capacitor	1	150990400	-	150990420	-	150990420	-	150990440	-
18	Cop. scatola mors.	Terminal box cover	1	Vedi item 19 - Pls see item 19							
19	Scatola morsettiera	Terminal box	1	KL30AAA							
20	Guarniz. scatola mors.	Terminal box gasket	1								
21	Pressacavo M20X1,5	Cable gland M20X1,5	1	002858761							
22	Tappo carico/scarico	Drain/ Fill plug	2	168400090							
	OR	OR	2	002221706							
23	Rondella spallamento tenuta	Seal shoulder washer	1	168301140							
24	Dado arresto girante	Impeller fixing washer	1	168301120							
25	Tirante	Tie rod	3								
26	Distanziale girante	Impeller spacer	N+N	162502370							
27	Guarniz. scatola mors.	Terminal box gasket	1								
28	Piede di sostegno	Support foot	1	-				161409720		161409730	KL23AAA

* Parti di ricambio consigliate - Recommended spare parts

Set OR HM/S (ORings of item : 13 ; 22) EPDM ---> KL02ABZ

Set OR HM/S (ORings of item : 13 ; 22) FPM ---> KL02AB0

Set OR HM/S (ORings of item : 13 ; 22) NBR ---> KL02AB1

N = Number of stages

N = Numero di stadi

(Nota) - Motoprotettore insieme al connettore "Plug-in"

(Note) - Overload protection together to "Plug-in" element

