





PARTI DI RICAMBIO - SPARE PARTS LIST

2HMS Serie - Series

ITEM N.	DESCRIZIONE	DESCRIPTION	Q.TA' Q.TY	CODICE - CODE							
				2HMS3/A	2HMS3T/A	2HMS4R/A	2HMS4RT/A	2HMS4/A	2HMS4T/A	2HMS7/A	2HMS7T/A
				107310000	107310050	107310010	107310060	107310020	107310070	107310030	107310080
				0,3 kW	0,3 kW	0,45 kW	0,45 kW	0,45 kW	0,45 kW	0,75 kW	0,75 kW
1	Corpo pompa	Pump body	1	151301640		151301650		151301720		151301730	
*	2	Girante	N	150702160							
3	Scatola stadio iniziale	Initial stage box	1	152801060							
4	Diffusore	Diffuser	N-2	-		152800900					
5	Diffusore finale	Final diffuser	1	152801300							
6	Disco portatenuta	Seal holding disc	1	160102430							
7	Supporto motore/pompa	Motor/pump support	1	161430650						161430660	
8	Albero-rotore-cuscinetti-sporg.	Shaft-rotor-bearings-extension	1	155108080		155108090		155108100		155108111	155108110
9	Cassa motore c/statore	Motor case w/stator	1	KR0100000	KR0100100	KR0100200	KR0100300	KR0100200	KR0100300	KR0100800	KR0100900
10	Coperchio motore	Motor cover	1								
11	Ventola	Fan	1	140760150							
12	Copriventola	Fan cover	1	164260800						164260810	
*	13	Tenuta meccanica + OR	1	148992571							
*	14	Cuscinetto ant.	1	002312702						002312732	
		Cuscinetto post.	1	002312702						002312702	
15	Anello tenuta ant. (V ring)	Front Seal ring (V ring)	1	002220410							
	An. tenuta post. (an. cuscinetto)	Rear Seal ring (Beck bearing)	1	002651507							
16	Connettore Plug-in	Plug-in element	1	158160600	158160280	158160620	158160280	158160620	158160280	158160680	158160280
17	Condensatore	Capacitor	1	150990400	-	150990420	-	150990420	-	150990440	-
18	Cop. scatola mors.	Terminal box cover	1	154060270							
19	Scatola morsettiera	Terminal box	1	151360200							
20	Guarniz. scatola mors.	Terminal box gasket	1								
21	Pressacavo	Cable gland	1								
22	Tappo carico/scarico	Drain/ Fill plug	2	168400090							
	OR	OR	2	002221706							
23	Rondella spallamento tenuta	Seal shoulder washer	1	168301140							
24	Dado arresto girante	Impeller fixing washer	1	168301120							
25	Tirante	Tie rod	3								
26	Distanziale girante	Impeller spacer	N+N	162502370							
27	Guarniz. scatola mors.	Terminal box gasket	1								
28	Piede di sostegno	Support foot	1								

* Parti di ricambio consigliate - Recommended spare parts

Set OR HM/S (ORings of item : 13 ; 22) EPDM ---> KL02ABZ

Set OR HM/S (ORings of item : 13 ; 22) FPM ---> KL02AB0

Set OR HM/S (ORings of item : 13 ; 22) NBR ---> KL02AB1

N = Number of stages

N = Numero di stadi

(Nota) - Motoprotettore insieme al connettore "Plug-in"

(Note) - Overload protection together to "Plug-in" element

