





LISTA PARTI DI RICAMBIO - SPARE PARTS LIST

4HMS Serie - Series

ITEM N.	DESCRIZIONE	DESCRIPTION	Q.TA' Q.TY	CODICE - CODE							
				4HMS3/A	4HMS3T/A	4HMS4/A	4HMS4T/A	4HMS5/A	4HMS5T/A	4HMS7/A	4HMS7T/C
				107310100 0,3 kW	107310150 0,3 kW	107310110 0,45 kW	107310160 0,45 kW	107310120 0,55 kW	107310170 0,55 kW	107310130 0,75 kW	104260230 0,75 kW
1	Corpo pompa	Pump body	1	151301640		151301650		151301720		151301730	
*	Girante	Impeller	N	150702170							
3	Scatola stadio iniziale	Initial stage box	1	152801060							
4	Diffusore	Diffuser	N-2	-		152800900					
5	Diffusore finale	Final diffuser	1	152801300							
6	Disco portatenuta	Seal holding disc	1	160102430							
7	Supporto motore/pompa	Motor/pump support	1	161430650					161430660	161430800	
8	Albero-rotore-cuscinetti-sporg.	Shaft-rotor-bearings-extension	1	155108080		155108090		155108100		155108111	155108300
9	Cassa motore c/statore	Motor case w/stator	1	KR0100000	KR0100100	KR0100200	KR0100300	KR0100400	KR0100500	KR0100800	KL25AC6
10	Coperchio motore	Motor cover	1								
11	Ventola	Fan	1	140760150							
12	Copriventola	Fan cover	1	KL29AAC					KL29AAD	KL29AAE	
*	Tenuta meccanica + OR	Mechanical seal + OR	1	148992571							
*	Cuscinetto ant.+ post.	Front + rear bearing	1	KL11AAA					KL11AAB	KL11AAC	
15	Anelli tenuta	Seal rings	1	KL03ABP							
16	Connettore Plug-in	Plug-in element	1	158160600	158160280	158160620	158160280	158160640	158160280	158160680	158160280
17	Condensatore	Capacitor	1	150990400	-	150990420	-	150990430	-	150990450	-
18	Cop. scatola mors.	Terminal box cover	1	Vedi item 19 - Pls see item 19							
19	Scatola morsettiera	Terminal box	1	KL30AAA							
20	Guarniz. scatola mors.	Terminal box gasket	1								
21	Pressacavo M20X1,5	Cable gland M20X1,5	2	002858761							
22	Tappo carico/scarico	Drain/ Fill plug	2	168400090							
	OR	OR	1	002221706							
23	Rondella spallamento tenuta	Seal shoulder washer	1	168301140							
24	Dado arresto girante	Impeller fixing washer	1	168301120							
25	Tirante	Tie rod	3								
26	Distanziale girante	Impeller spacer	N+N	162502370							
27	Guarniz. scatola mors.	Terminal box gasket	1								
28	Piede di sostegno	Support foot	1	-		161409720			161409730	KL23AAA	

* Parti di ricambio consigliate - Recommended spare parts
 Set OR HM/S (ORings of item : 13 ; 22) EPDM ----> KL02ABZ
 Set OR HM/S (ORings of item : 13 ; 22) FPM ----> KL02AB0
 Set OR HM/S (ORings of item : 13 ; 22) NBR ----> KL02AB1

N = Number of stages
 N = Numero di stadi

(Nota) - Motoprotettore insieme al connettore "Plug-in"
 (Note) - Overload protection together to "Plug-in" element

